


# ATLANTIS WATER BOILER PARTS LIST



Fracino Ltd.  
17-19 Birch Road East  
Birmingham  
B6 7DA

Tel: 0121 328 5757  
Fax: 0121 327 3333  
email: [sales@fracino.com](mailto:sales@fracino.com)


## Contents

### Page

3-4	Parts list
5	Bodywork
6	Boiler and Internal Components
7	Valve Assembly
8	Wiring Diagram
9	Wiring Diagram 6Kw Supplement


Part No.	Description	Quantity
<b>BODYWORK</b>		
WB120	Top Cover	1
WB250	Steam Thermostat Fitting	1
WB166	Steam Thermostat 100°c	1
FC76	Washer	1
FC75D	¼ " BSP Locknut	1
WB200	Rear Panel	1
FC189	On/Off Switch	1
FC157/25	Cable Restraining Bush	1
HEA260	Feet	4
WB213	Body Panel	1
FC190	Neon Amber	1
FC190/R	Neon Red	1
WB222F	Grommet	1
WB201	Base Plate	1
SOL171	Inlet Solenoid	1
FC136FW	Hose Filter Washer	1
FC136W	Hose Seal	1
SOL137	Inlet Hose S/S Braided	1
SOL1	Silicone Tube	1
SOL205	Cup Tray	1
WB204	Drip Tray	1
WB120	Condensation Drain	1
WB120C	Overflow Fitting Spring Clip	1
FC158/M	6mm Mains Cable 6KW only	1
FC158	Cable and Plug 3KW only	1
<b>BOILER &amp; INTERNAL COMPONENTS</b>		
WB191A	Low Level Probe	1
WB191	Level Probe	1
SOL165	Element and Fitting Seals	8
SOL162	Element 2.85KW Incalloy	1 (3KW) 2 (6KW)
SOL165	Element Gasket	2/4
FC75D	¼ BSP Locknut	6
WB166A	3KW High Limit Thermostat Fitting	1
WB166B	6KW High Limit Thermostat Fitting	1
HEA166	3KW High Limit Thermostat	1
WB083	Temperature Sensor	1
SOL165	Pipe Seal	4
WB172	Electronic Water and Temperature Controller	1
WB150	Electronics MTG Plate	1
WB081	Boiler Lid	1
WB100	Boiler Gasket	1
WB185	¼ " BSP Blank Plug 3KW only	2

Part No.	Description	Quantity
WB80	Boiler 19L	1
FC191C	Terminal Block	1
FC166HLS	High Limit Thermostat 6KW only	1
WB166B	¼ BSP Tube Fitting (8mm) 6KW only	1
FC157A	Terminal Block 6KW	1
SOL/A	Drain Bung	1
SOL1	Silicone Tube	1
FC174	Power Relay 6KW only	1
WB159	Wiring Harness 3KW	1
WB159/6	Wiring Harness 6KW	1
	<b>VALVE ASSEMBLY</b>	
WB196	½ " BSP Locknut	1
WB222G	Pipe Seal Valve Extension	1
WB220	Valve Extension	1
WB220B	Special Valve Compression Nut	1
WB220A	Tapered Seal	1
WB222A	Non Drip Valve Body	1
WB198	Pad Washer	1
WB222V	Valve Stem	1
WB222U	Valve Spring	1
WB222R	Valve Head	1
WB222H	Valve Handle	1
WB222J	Valve Handle Pivot Bolt	1
WB222K	Valve Handle Pivot Nut	1
WB222AS	Dispense Extension	1
WB222C	Collar	1
WB222S	O Ring	2




# BODYWORK






# VALVE ASSEMBLY

© Fracino 2006



# WIRING DIAGRAM





# WIRING DIAGRAM 6KW SUPPLEMENT